ledix

LED lighting fitting MOZA


with a radio receiver



A lighting fitting with a built-in radio receiver cooperating with transmitters of EXTA FREE system



Mounting indoor only



MOZA with a built-in radio receiver is a high quality LED fitting with decorative and application features. It is used for lighting corridors, passageways, for decorative lighting of furniture and lighting arrangement in the interior design. The features of the fitting:

- luminous flux emitted in two planes: lower and front
- wireless control cooperation with chosen wireless transmitters of EXTA FREE system,
- realisation one out of three operation modes: switch on / switch off (ON/OFF), brightening/ dimming, time mode with dimming,
- excellent lighting parameters obtained by applying the highest quality LED diodes
- high quality and durability estimated to light continuously for five year.

CAUTION:

 Power supplies of ZNP and ZNN series and of ZNM series in 14 V DC version by Cet Lighting are used to supply the fittings.

Application:

SCAN



stairs



corridors, passageways



RNP-01 RNP-02 RNM-10 RXM-01 RTI-01 RCR-01
Operation range from 40 to 50 m in the open area



furniture, decorative lighting

za/MeL cet

Cet Lighting Sp. z o.o. PL 43-200 Pszczyna, ul. Zielona 27, Poland tel: +48 32 449 15 00, fax: +48 32 449 15 02 e-mail: ledix@ledix.pl, www.ledix.pl

14 V DC; IP20 weight: 171 g

Cet Lighting Sp. z o.o. declares that the device is consistent with the essential requirements and other relevant provisions of the RTTE Directive.





The symbol means selective collecting of electrical and electronic equipment. It is forbidden to put the used equipment together with other waste.

14VDC ledix

LED lighting fitting

MOZA
with a radio receiver



TRANSMITTERS' DELETION



Press PROG push-button in the fitting for a longer time



After 5 seconds STATUS LED red diode switches on and switches off




Release PROG push-button in the fitting - THE MEMORY IS DELETED

INSTALLATION EXAMPLE

ZNP, ZNN or ZNM power supply

in 14 V DC version



MOUNTING


N 230 V AC

The device is designed for single-phase installation and must be installed in accordance with standards valid in a particular country. Installation, connection and control should be carried out by a qualified electrician staff, who act in accordance with the service manual and the device functions.

Fitting is designed for mounting in Ø60 junction box.

14 V DC

- 1. Disconnect power supply by the phase fuse, the circuit-breaker or the switch- disconnector combined to the proper circuit.
- 2. Check if there is no voltage on connection cables by means of a special measure equipment.
- 3. Connect the 14 V DC power supply to 230 V AC.
- Remove the fitting with the help of fingers hold the control module and move the fitting upward (as shown in the Figure) and gently pull away from the mounting element.
- 5. Disconnect the connecting cables between the fitting and the control module.
- 6. Connect the installation cables into the appropriate terminals of the control module in accordance with the selected connection diagram, maintaining the correct polarity.
- 7. Mount the control module in a Ø60 iunction box and tighten the screws.
- Add a transmitter to a lighting fitting. A detailed description referring to these activities is in the operation mode programming section.
- Connect the fitting cables with the module mounted in Ø60 junction box.
- Mount the front of the fitting on the mounting element.
- Switch on the power supply from the mains.
- 12. Check if the fitting works properly.



TECHNICAL DATA				
Supply voltage	14 V DC			
Power consumption	0,74 W – cold white 0,60 W – warm white 0,46 W – red 0,46 W – green 0,46 W – blue			
	cold white	warm white		
Colour rendering index Ra	71	80		
Colour temperature T _C [K]	5900	3100		
Luminous flux Ø [lm]	19	13		
Luminous efficiency [lm/W]	34	31		
Protection degree suitable for indoor use only	4xLED Light source	e - four LED diodes		

COOPERATION WITH EXTA FREE TRANSMITTERS

cooperates with chosen transmitters

The fitting cooperates

with photovoltaic cells
The lighting fitting

of EXTA FREE system


MOZA lighting fitting with a built-in radio receiver cooperates with chosen wireless transmitters of EXTA FREE system (www.extafree.pl). The operation range depends on the transmitter's type.

Transmitter's symbol	Mounting	Range* [m]	Operation modes
RNK-02	surface	50	
RNK-04		50	
RNP-01	flush	40	
RNP-02		40	ON/OFF mode
RNM-10	TH-35 rail	50	Dei alabasa in a (disasaria a
RXM-01		50	Brightening/dimming
P-257/2	portable remote control	40	Time mode
P-257/4		40	
P-256/8		50	
RTI-01	RTI-01 surface	40	
RCR-01		40	ON/OFF mode

^{*} CAUTION: The given range concerns open area - an ideal condition without any natural or artificial obstacles. If there are some obstacles between a transmitter and a receiver, it is advisable to decrease the range according to: bricks: from 10 to 40% wood and plaster: from 5 to 20%, reinforced concrete: from 40 to 80%, metal: from 90 to 100%, glass: from 10 to 20%. Over- and underground medium and high electrical power lines, radio and television transmitters, GSM transmitters set dose to a device system have also a negative influence on the range.

OPERATION MODES

The operating mode is defined during transmitters' programming phase. The programming procedure is simply adding a specific transmitter to a selected LED fitting with a built-in radio receiver. Different functions can be assigned to each transmitter depending on how it is added to the lighting fitting. 32 transmitters of EXTA FREE system can be added to a single fitting. Full transmitters' memory is indicated by a pulsating STATUS LED red diode in the programming stage of subsequent transmitters.




Built-in LED diode current stabilization system

ON/OFF MODE



Press PROG push-button in the fitting for a longer time until STATUS LED red diode switches on (constant signal)



Press and release the first transmitter's push-button (ON). STATUS LED red diode switches on (first signal pulsates, next the signal is constant)



Press and release the second transmitter's push-button (OFF). STATUS LED red diode switches on (the signal pulsates) and next it switches off - THE TRANSMITTER IS ADDED

ON / OFF mode is realised only on two different transmitter's push-buttons.

In this mode, the fitting is switched on by pressing the programmed push-button as (ON) and switched off by pressing by pressing the programmed push-button as (OFF).

BRIGHTENING/DIMMING MODE


Brightening/dimming mode is realised only on two different transmitter's push-buttons.

In order to realise the brightening / dimming the transmitter should be programmed in ON / OFF mode (see above). Pressing the (ON) push-button for a longer time (> 3s) realises the brightening function to the maximum level. Pressing the (OFF) push-button for a longer time (> 3s) realises the dimming function to the minimum level.

TIME MODE



Press PROG push-button in the fitting for a longer time until STATUS LED red diode switches on (constant signal)




Press and release the transmitter's push-button. STATUS LED red diode switches on (first signal pulsates. next the signal is constant)

Press and release the same transmitter's push-button. STATUS LED diode switches on (the signal pulsates) and next it switches off - THE TRANSMITTER IS ADDED


Time mode is realised only on one transmitter's push-buttons.

The fitting switches on by pressing the chosen transmitter's push-button and switches off automatically after the programmed time is over (from 1 s to 18 h) or by pressing the transmitter's push-button again. Switching off is carried out by smooth dimming for time t ~ 10 s. Each time the chosen transmitter's push-button is pressed during dimming causes the time is counted again (retrigable time). In time mode, brightening / dimming is realised by longer pressing the chosen push-button.

TIME PROGRAMMING



Press PROG push-button in the fitting for a longer time until STATUS LED red diode switches on (constant signal) Wait for about 5 seconds till STATUS LED diode switches on again (first signal pulsates, next the signal is constant)



Press and release the PROG push-button in the fitting. STATUS LED red diode switches off and next it switches on (the signal pulsates). Each STATUS diode pulse means 1 second. The maximum time is 18 hours



After counting the programmed time press the PROG push-button and then release it -TIME IS ADDED

COOPERATION WITH RCR-01 RADIO MOTION SENSOR

The fitting cooperates with RCR-01 radio motion sensor (www.extafree.pl). It includes two modes:

MODE 1 - only the motion sensor. Change the RCR-01 switch into "C" position.



Press NAUKA push-button of RCR-01, next release the push-button. LED red diode switches on under the lens (constant signal)



Press PROG push-button to adjust the fitting to the programming mode, STATUS LED red diode in the fitting switches on (constant signal)



Press NAUKA push-button of RCR-01 device and then release it. STATUS LED red diode in the fitting switches on (first signal pulsates, next the signal is constant)



Press NAUKA push-button of RCR-01 device and then release it. STATUS LED red diode in the fitting switches on (signal pulsates) - THE SENSOR IS ADDED. Wait until LED diode in RCR-01 device switches off

Additionally, in this mode, time programming should be done in the fitting. The time value should be adjusted to the minimum of 15 seconds. The cooperation between the motion sensor and the fitting is that while in the detection zone the sensor detects movement, it sends a signal every 10 seconds to the fitting. After the signal has been sent, time counting starts from the beginning.

CAUTION: Each time a push-button is pressed in the motion sensor there are 10 seconds to start the next step of the programming procedure. After this time, the sensor begins normal operation.

MODE 2 - motion sensor with a twilight switch. Change the RCR-01 switch into "F" position.



Press NAUKA push-button of RCR-01, next release the push-button. LED red diode switches on under the lens (constant signal)



in RCR-01


for a longer

time

Press NAUKA Press PROG push-button again push-button to adjust the fitting to the programming mode. STATUS LED red diode in the

Release NAUKA push-button of RCR-01. STATUS LED red diode in the fitting switches on fitting switches on (first signal pulsates, (constant signal) next the signal

is constant)



Press NAUKA push-button of RCR-01, next release the push-button. STATUS LED red diode in the fitting switches on (signal pulsates) and switches off. THE SENSOR IS ADDED Wait until LED diode in RCR-01 switches off

The cooperation between the motion sensor and the fitting is that while in the detection zone the sensor detects movement, it sends a switch on signal to the fitting. The switch off signal is sent by the sensor after 20 seconds from the time of no motion in the detection zone.

CAUTION: Each time a push-button is pressed in the motion sensor there are 10 seconds to start the next step of the programming procedure. After this time, the sensor begins normal operation.